

## MOUNTING INSTRUCTIONS / SKI-BRAKES MEIDJO 2.1

(ANG/FR)

1- Put the ski-brake in the place provided for this purpose between the low-tech plate and the base plate / Poser le stop-ski à l'endroit prévu à cet effet entre la sous-platine et la plaque arceau



2- Remove the cap located in the middle of the ASP (Anti-Snow Pack) plate then screw the ASP plate / Retirer le capuchon situé au milieu de la plaque ASP (Anti-Snow Pack) puis visser la plaque ASP



3- Insert the low-tech and continue mounting the binding as indicated on the binding instruction / Enfiler le low-tech puis continuer le montage de la fixation comme indiquée sur la notice de la fixation.

